



NeilPryde Sailing Bouyancy Aid Size Chart

Elite

Size	CM	KG	N
XS-S	86-96	40-60	40
M-L	97-106	60-70	45
XL-2XL	107-116	70 +	50
3 XL+	117-132	70 +	50

Raceline Overhead

Size	CM	KG	N
S	86-96	40-60	40
M	96-106	60-70	45
L	106-116	70+	50
XL	116-127	70+	50

Raceline Front Zip

Size	CM	KG	N
JNR	76-86	30-40	35
S/M	86-106	40-70	45
L/XL	106-127	70+	50